

TOSHIBA

FILE NO. 020-9604

SERVICE MANUAL

COLOR TELEVISION

N5E Chassis

CF13F22, CL14F22

(TAC9611)


(TAC9611)

CF19F22, CL20F22


(TAC9610)

(TAC9610)

CF13F22/ CL14F22




CF19F22/ CL20F22




Menu Function (General Instructions)

We suggest you familiarize yourself with the procedure before using the Menu function. To adjust any TV feature, the use of the Menu function is required. The adjustments that can be made to the TV appear on the screen.





MENU button (on Remote)

Each time you press **MENU**, the Picture, Audio, Setup or Option menu on-screen display is selected in order, then press **ADV**.



MENU button (on TV)

Each time you press **MENU**, each item will be selected in order, then press < or >.



ADV button (on Remote)

Use **ADV** after you have selected the on-screen menu you want to adjust with the **MENU** button.

Each time you press **ADV**, the function to be adjusted will be selected in order.

- ADV ▲ button from bottom to top
 - ADV ▼ button from top to bottom
- The selected function will be displayed in magenta.

</> (</>) buttons (on TV and on Remote)

Use </> (</>) to adjust the function you have selected with the **ADV** button on the Remote Control (or **MENU** button on the TV).



RECALL button (on Remote)

The above four menu displays will automatically disappear from the screen if no control has been operated for about 6 seconds. If you want to clear the screen of all on-screen displays instantly, press **RECALL**.

Note: The </> buttons on the TV will function as the **VOLUME** ▼/▲ buttons when no menu display is on the screen.

Programming Channel Memory

The channel memory is the list of TV channel numbers your TV will stop on when you press the CHANNEL ▲ or ▼ button. **First, use the TV/CABLE and CH PROGRAM functions to preset all active channels in your area.** If necessary, arrange the preset channels with the ADD/ERASE functions so that you can tune into only desired channels.



TV/CABLE function

- 1 Press **POWER** to turn on the TV.
- 2 Press **MENU** (then **ADV ▲** or **▼**) repeatedly until "TV/CABLE" in the Set up menu is displayed in magenta.
- 3 Press ◀ (<) or ▶ (>) until the mode that corresponds to your TV signal system is displayed in magenta. Each time you press the button, the TV*, STD*, HRC* or IRC* mode will be selected in order.

```
TV/CABLE: [TV]STD HRC IRC
CH PROGRAM
ADD/ERASE: [ADD]ERASE
CH LOCK: 0 0 0 0
C CAPTION: [C1]C2 T1 T2 OFF
```

TO SELECT ITEM PUSH MENU
TO CONTROL PUSH - +

```
TV/CABLE: [TV]STD HRC IRC
CH PROGRAM
ADD/ERASE: [ADD]ERASE
CH LOCK: 0 0 0 0
C CAPTION: [C1]C2 T1 T2 OFF
```

TO SELECT ITEM PUSH MENU
TO CONTROL PUSH - +

CH PROGRAM function

- 1 Press **MENU** (then **ADV ▲** or **▼**) repeatedly until "CH PROGRAM" in the Set up menu is displayed in magenta.
- 2 Press ◀ (<) or ▶ (>) to start channel programming. The TV will automatically cycle through all the TV or CABLE channels depending on the mode selected, and store active channels in the channel memory.
- 3 When channel programming is complete, you will see the message at the right.
- 4 Press **CHANNEL ▲** or **▼** to make sure the channel programming has been done properly.

```
TV/CABLE: [TV]STD HRC IRC
CH PROGRAM
ADD/ERASE: [ADD]ERASE
CH LOCK: 0 0 0 0
C CAPTION: [C1]C2 T1 T2 OFF
```

TO SELECT ITEM PUSH MENU
TO CONTROL PUSH - +

```
CH PROGRAM
TV 24
```

```
CH PROGRAMMING
COMPLETED
TV 4
```

* This TV receives the following TV signals:


1. **TV:** TV broadcasts signals. (VHF channels 2 through 13 and UHF channels 14 through 69)
2. **STD CABLE:** Standard cable TV signals.
3. **HRC CABLE:** Harmonic Related Carrier cable TV signals.
4. **IRC CABLE:** Incremental Related Carrier cable TV signals.

If you are not sure what CABLE system they are using, consult your local CABLE company.


ADD/ERASE function

After performing the CH PROGRAM function, you can add or erase specific channels.


- 1 Select the channel you want to erase using the **CHANNEL ▲** or **▼** button, or select the channel you want to add using the **Channel Number** buttons.




- 2 Press **MENU** (then **ADV ▲** or **▼**) repeatedly until "ADD/ERASE" in the Set up menu is displayed in magenta.



- 3 Press **◀ (<)** or **▶ (>)**:
To erase the channel
 Press the button until "ERASE" is displayed in magenta indicating that the channel has been erased from the memory.



- To add the channel**
 Press the button until "ADD" is displayed in magenta indicating that the channel has been memorized.



- 4 Repeat steps 1 to 3 for other channels.

You have now completed the channel programming.

CABLE channel reference chart

Number on this TV	Corresponding CABLE channel	Number on this TV	Corresponding CABLE channel
1	A-8	67	67
5	5 (A-7)	68	68
6	6 (A-6)	69	69
14	A
15	B	92	92
16	C	93	93
.....	94	94
34	U	95	A-5
35	V	96	A-4
36	W	97	A-3
37	AA	98	A-2
38	BB	99	A-1
.....	100	100
60	XX	101	101
61	YY	102	102
62	ZZ
63	AAA	123	123
64	BBB	124	124
65	65	125	125
66	66		

The above chart is typical of many cable system channel allocations. If in doubt, consult your cable company.

WARNING: BEFORE SERVICING THIS CHASSIS, READ THE "X-RAY RADIATION PRECAUTION", "SAFETY PRECAUTION" AND "PRODUCT SAFETY NOTICE" ON PAGE 2 OF THIS MANUAL.

SET-UP ADJUSTMENT

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
Perform the adjustments in order as follows :
 1. Color Purity
 2. Convergence
 3. White Balance (See page 15.)Note: The PURITY/CONVERGENCE MAGNET assembly and rubber wedges need mechanical positioning.
Refer to figure 1.

COLOR PURITY ADJUSTMENT

NOTE : Before attempting any purity adjustments, the receiver should be operated for at least fifteen minutes.

1. Demagnetize the picture tube and cabinet using a degaussing coil.
2. Set the brightness and contrast to maximum.
3. Use a green raster from among the built-in test signals. See page 13.
4. Loosen the clamp screw holding the yoke and slide the yoke backward or forward to provide vertical green belt (zone) in the picture screen.

5. Remove the Rubber Wedges.
6. Rotate and spread the tabs of the purity magnet (See figure 2.) around the neck of the picture tube until the green belt is in the center of the screen. At the same time, enter the raster vertically.
7. Slowly move the yoke forward or backward until a uniform green screen is obtained. Tighten the clamp screw of the yoke temporarily.
8. Check the purity of the red and blue raster.




Figure 1.

CONVERGENCE ADJUSTMENTS




NOTE: Before attempting any convergence adjustments, the receiver should be operated for at least fifteen minutes.

■ CENTER CONVERGENCE ADJUSTMENT

1. Use the cross-dot pattern from among the built-in test signals. See page 13.
2. Set the brightness and contrast for well defined pattern.
3. Adjust two tabs of the 4-Pole Magnets to change the angle between them (See figure 2.) and superimpose red and blue vertical lines in the center area of the picture screen.
4. Turn the both tabs at the same time keeping the angle constant to superimpose red and blue horizontal lines at the center of the screen.
5. Adjust two tabs of 6-Pole Magnets to superimpose red/blue line and green one. Adjusting the angle affects the vertical lines and rotating both magnets affects the horizontal lines.
6. Repeat adjustments 3, 4, 5 keeping in mind red, green and blue movement, because 4-Pole Magnets and 6-Pole Magnets have mutual interaction and make dot movement complex.

■ CIRCUMFERENCE CONVERGENCE ADJUSTMENT

1. Loosen the clamping screw of deflection yoke slightly to allow the yoke to tilt.
2. Temporarily put a wedge as shown in figure 1. (Do not remove cover paper on adhesive part of the wedge.)
3. Tilt front of the deflection yoke up or down to obtain better convergence in circumference. (See figure 3.) Push the mounted wedge into the space between picture tube and the yoke to fix the yoke temporarily.
4. Put other wedge into bottom space and remove the cover paper to stick.
5. Tilt front of the yoke right or left to obtain better convergence in circumference. (See figure 3.)
6. Keep the yoke position and put another wedge in either upper space. Remove cover paper and stick the wedge on picture tube to fix the yoke.
7. Detach the temporarily mounted wedge and put it in another upper space. Stick it on picture tube to fix the yoke.
8. After fixing three wedges, recheck overall convergence. Tighten the screw firmly to fix the yoke and check the yoke is firm.
9. Stick three adhesive tapes on wedges as shown in figure 1.








Figure 2.




4-POLE MAGNETS MOVEMENT




6-POLE MAGNETS MOVEMENT

Center Convergence by Convergence Magnets



INCLINE THE YOKE UP (OR DOWN)




INCLINE THE YOKE RIGHT (OR LEFT)

Circumference Convergence by DEF Yoke


Figure 3. Dot Movement Pattern

ENTERING TO SERVICE MODE


1) Press MUTE button once on Remote Control.



2) Press MUTE button again to keep pressing.




3) Keep pressing the MUTE button, press MENU button on TV set.



(Service mode display)

DISPLAYING THE ADJUSTMENT MENU

1) Press MENU button on TV.



SELECTING THE ADJUSTING ITEMS

1) Every pressing of CHANNEL ▲ button changes the adjustment items in the following order. (▼ button for reverse order.)

Address	Function to be adjusted	Reference data	
		CF13F22/CL14F22	CF19F22/CL20F22
☆ RCUT	RED CUT-OFF	40H	←
☆ GCUT	GREEN CUT-OFF	40H	←
☆ BCUT	BLUE CUT-OFF	40H	←
☆ GDRV	GREEN DRIVE	80H	←
☆ BDRV	BLUE DRIVE	80H	←
CNTX	SUB-CONTRAST	50H	←
☆ BRTC	SUB-BRIGHTNESS	38H	←
☆ COLC	SUB-COLOR	2CH	←
☆ TNTC	SUB-TINT	42H	←
☆ HPOS	HORIZONTAL POSITION	1AH	19H
☆ VPOS	VERTICAL POSITION	02H	02H
☆ HIT	HEIGHT	20H	20H

☆ These adjustments may be required when replacing QA02 and Q501.

ADJUSTING THE DATA


1) Pressing of VOLUME ▲ or ▼ button will change the value of data in the range from 00H to FFH. The variable range depends on the adjusting item.

EXIT FROM SERVICE MODE

1) Press POWER button to turn off the TV once.

TEST SIGNAL SELECTION

1) Every pressing of TV/VIDEO button changes the built-in test patterns on screen in the following order.



Note: If the video cable is connected to the VIDEO INPUT jack, the built-in pattern signals are not displayed.

Signals	Picture
<ul style="list-style-type: none"> • Red raster • Green raster • Blue raster • All Black • All White 	
<ul style="list-style-type: none"> • Black cross-bar • White cross-bar 	
<ul style="list-style-type: none"> • Black cross-hatch • White cross-hatch 	
<ul style="list-style-type: none"> • Black cross-dot • White cross-dot 	

INITIALIZATION OF MEMORY DATA OF QA02

After replacing QA02, the following initialization is required.

1. Enter the service mode, then select any register item.
2. Press and hold the RECALL button on the Remote, then press the CHANNEL button on the TV. The initialization of QA02 has been completed.
3. Check the picture carefully. If necessary, adjust any adjustment item above. Perform "Programming Channel Memory" on page 6.






CAUTION: Never attempt to initialize the data unless QA02 has been replaced.


SELF DIAGNOSTIC FUNCTION

- 1) Press "9" button on Remote Control during display of adjustment menu. The diagnosis will begin to check if interface among IC's are executed properly.
- 2) During diagnosis, the following displays are shown.

NO. 23905436	→	Part number of microprocessor (QA01)
SELF CHECK	→	
POWER : 000	→	Operation number of protecting circuit ---- "000" is normal.
BUS : OK	→	BUS line check ---- "OK" is normal.
NO ACK :	→	"[blank]" is normal.

ELECTRICAL ADJUSTMENT

ITEM	ADJUSTMENT PROCEDURE
<p>FOCUS VR ADJ.</p> 	<ol style="list-style-type: none"> 1. Enter the service mode, then select any register item. 2. Press the TV/VIDEO button on the Remote until the black cross-bar pattern appears on the screen. 3. Adjust the FOCUS control (on T461) for well defined scanning 24 lines on the picture screen.
<p>SUB-BRIGHTNESS (BRTC)</p> 	<ol style="list-style-type: none"> 1. Constrict the picture height until the vertical retrace line appears adjusting the HEIGHT control on the MAIN board. 2. Adjust the CONTRAST to the minimum and BRIGHTNESS to the center. 3. Enter the service mode, then select "BRTC" register. 4. Adjust the data value so the belt of vertical retrace line just disappear. 5. Adjust the CONTRAST for the desired contrast. 6. Adjust the HEIGHT control. 
<p>SUB-COLOR (COLC) SUB-TINT (TNTC)</p>	<ol style="list-style-type: none"> 1. Receive color-bar signal from color-bar generator. 2. Adjust the BRIGHTNESS and CONTRAST to the center (RESET status). 3. Connect oscilloscope pin 23 of Q501 on the MAIN board. 4. Enter the service mode, then select "COLC". 5. Temporarily adjust the data value to achieve about $1V_{0-p}$ of blue bar. 6. Select "TNTC" register. 7. Adjust the data value to obtain the blue bar to magenta bar ratio of 3:2 as shown. 8. Select "COLC" register. 9. Adjust the data value to achieve $1.8V_{0-p}$ of blue bar on scope. 10. Check the picture with off-air signal. 
<p>HORIZONTAL POSITION (Address : HPOS) VERTICAL POSITION (Address : VPOS)</p>	<ol style="list-style-type: none"> 1. Call up the adjustment mode display, then select the address HPOS or VPOS. 2. Press the TV/VIDEO button until the white cross-bar or black cross-bar pattern appears on the screen. 3. Adjust the HORIZONTAL and VERTICAL position alternately by pressing the VOLUME ▲ or ▼ button for proper picture position. 4. Check the picture with off-air signal. 
<p>HEIGHT (Address : HIT)</p>	<ol style="list-style-type: none"> 1. Call up the adjustment mode display, then select the address HIT. 2. Press the VOLUME ▲ or ▼ button to get the picture so the top of raster begins to lack. 3. Press the VOLUME ▲ button to advance the data by 8 steps. <p>Note : Check the vertical picture position is correct.</p>

ITEM	ADJUSTMENT PROCEDURE
<p>WHITE BALANCE Address : RCUT Address : GCUT Address : BCUT Address : GDRV Address : BDRV</p>	<ol style="list-style-type: none"> Adjust the CONTRAST control to the center, and BRIGHTNESS control to the maximum. Call up the adjustment mode display, and press the TV/VIDEO button until the white and black pattern appears on the screen. Adjust the following address with the CHANNEL ▲/▼ and VOLUME ▲/▼ buttons. Address : RCUT → Data : 40H Address : GDRV → Data : 80H Address : GCUT → Data : 40H Address : BDRV → Data : 80H Address : BCUT → Data : 40H Press "100" button on the Remote Control to display a single horizontal line on the screen. Turn the SCREEN control (FBT) fully counterclockwise and gradually rotate clockwise until the first horizontal line appears slightly on the screen. Press "100" button to display the normal picture. Adjust the remaining two "?CUT" addresses (CHANNEL ▲/▼ → 100 → VOLUME ▲/▼ in order) to obtain the slightly lighted horizontal line in the same levels of three (red, green, blue) colors. The line should be white if the adjustments are proper. <div style="display: flex; align-items: center; margin-top: 10px;">  <div> <p>Bright area Adjust "GDRV" or "BDRV" to be white.</p> <p>Dark area Fine adjust "RCUT", "GCUT" or "BCUT" to be black.</p> </div> </div>

CIRCUIT ADJUSTMENT

HIGH VOLTAGE CHECK

CAUTION: There is no **HIGH VOLTAGE ADJUSTMENT** on this chassis. Checking should be done following the steps below.


- Connect an accurate high voltage meter to the second anode of the picture tube.
- Turn on the receiver. Set the **BRIGHTNESS** and **CONTRAST** controls to minimum (zero beam current).
- High voltage must be measured below 24.7 kV (13V) / 28.8 kV (19V).
- Vary the **BRIGHTNESS** control to both extremes to be sure the high voltage does not exceed the limit under any conditions.

FS CIRCUIT CHECK


The Fail Safe (FS) circuit check is indispensable for the final check in servicing. Checking should be done following the steps below.

- Turn the receiver on and press the **RESET** button.
- Temporarily short TP- Ⓡ and TP- ⓧ with a jumper wire.
Raster and sound will disappear.
- The receiver must remain in this state even after removing the jumper wire. This is the evidence that the FS circuit is functioning properly.
- To obtain a picture again, temporarily turn the receiver off and allow the FS circuit more than 5 seconds to reset. Then turn the power switch on to produce a normal picture.

Troubleshooting Guide for Fail Safe Circuit



CHASSIS BLOCK DIAGRAM



CHASSIS REPLACEMENT PARTS LIST

WARNING: BEFORE SERVICING THIS CHASSIS, READ THE "X-RAY RADIATION PRECAUTION", "SAFETY PRECAUTION" AND "PRODUCT SAFETY NOTICE" ON PAGE 2 OF THIS MANUAL.

CAUTION: The international hazard symbols "⚠" in the schematic diagram and the parts list designate components which have special characteristics important for safety and should be replaced only with types identical to those in the original circuit or specified in the parts list. The mounting position of replacements is to be identical with originals. Before replacing any of these components, read carefully the PRODUCT SAFETY NOTICE on page 2. Do not degrade the safety of the receiver through improper servicing.

NOTICE:

- The part number must be used when ordering parts, in order to assist in processing, be sure to include the Model number and Description.
- The PC board assembly with * mark is no longer available after the end of the production.

Models : CF13F22/ CL14F22

ABBREVIATIONS:

Capacitors.....	CD : Ceramic Disk	PF : Plastic Film	EL : Electrolytic
Resistors.....	CF : Carbon Film	CC : Carbon Composition	MF : Metal Film
	OMF : Oxide Metal Film	VR : Variable Resistor	FR : Fusible Resistor

(All CD and PF capacitors are ±5%, 50V and all resistors, ±5%, 1/6W unless otherwise noted.)

Location No.	Part No.	Description
CAPACITORS		
C101	24797100	EL, 10μF, ±20%, 50V
C102	24763101	EL, 100μF, ±20%, 16V
C103	24232103	CD, 0.01μF, +80%, -20%
C113	24794470	EL, 47μF, ±20%, 16V
C201	24797478	EL, 0.47μF, ±20%, 50V
C202	24794220	EL, 22μF, ±20%, 16V
C205	24794220	EL, 22μF, ±20%, 16V
C207	24794100	EL, 10μF, ±20%, 16V
C208	24797010	EL, 1μF, ±20%, 50V
C209	24797229	EL, 2.2μF, ±20%, 50V
C210	24794470	EL, 47μF, ±20%, 16V
C230	24794470	EL, 47μF, ±20%, 16V
C232	24092398	CD, 0.1μF, +80%, -20%
C233	24797100	EL, 10μF, ±20%, 50V
C301	24617912	EL, 2.2μF, ±10%, 50V
C302	24212152	CD, 1500pF, ±10%
C305	24617912	EL, 2.2μF, ±10%, 50V
C306	24073044	EL, 3300μF, ±20%, 16V
C307	24082047	PF, 0.033μF, 100V
C308	24668101	EL, 100μF, ±20%, 35V
C309	24591102	PF, 1000pF
C310	24796471	EL, 470μF, ±20%, 35V
C311	24214221	CD, 220pF, ±10%, 500V
C313	24082260	PF, 4700pF, 100V
C314	24590563	PF, 0.056μF
C315	24797229	EL, 2.2μF, ±20%, 50V
C317	24214471	CD, 470pF, ±10%, 500V
C403	24591203	PF, 0.02μF
C404	24797229	EL, 2.2μF, ±20%, 50V
C417	24214391	CD, 390pF, ±10%, 500V
C421	24794470	EL, 47μF, ±20%, 16V
C431	24794101	EL, 100μF, ±20%, 16V
△ C440	24082549	PF, 7500pF, ±3%, 1250V
△ C442	24082672	PF, 0.43μF, 250V
C445	24828223	PF, 0.022μF, 200V
C446	24700100	EL, 10μF, ±20%, 250V
C448	24640908	EL, 33μF, ±20%, 160V
C449	24794102	EL, 1000μF, ±20%, 16V
C463	24212152	CD, 1500pF, ±10%
C471	24797479	EL, 4.7μF, ±20%, 50V

Location No.	Part No.	Description
C474	24794100	EL, 10μF, ±20%, 16V
C504	24353090	CD, 9pF, ±0.25pF
C510	24797229	EL, 2.2μF, ±20%, 50V
C514	24591223	PF, 0.022μF
C515	24538104	PF, 0.1μF
C607	24797100	EL, 10μF, ±20%, 50V
C609	24591103	PF, 0.01μF
C610	24795220	EL, 22μF, ±20%, 25V
C611	24591104	PF, 0.1μF
C613	24794221	EL, 220μF, ±20%, 16V
C614	24797478	EL, 0.47μF, ±20%, 50V
C801	24082001	PF, 0.47μF, ±20%, AC125V
C810	24086052	EL, 220μF, ±20%, 200V
C811	24092270	CD, 4700pF, ±20%, AC400V
C812	24094820	CD, 2200pF, ±20%, AC400V
C815	24094820	CD, 2200pF, ±20%, AC400V
C819	24766478	EL, 0.47μF, ±20%, 50V
C840	24795471	EL, 470μF, ±20%, 25V
C842	24792101	EL, 100μF, ±20%, 6.3V
C843	24539104	PF, 0.1μF
C860	24214103	CD, 0.01μF, ±10%, 500V
C862	24591821	PF, 820pF
C863	24539104	PF, 0.1μF
C865	24092345	CD, 1000pF, ±10%, 2kV
C866	24669478	EL, 0.47μF, ±20%, 50V
C867	24212682	CD, 6800pF, ±10%
C868	24667101	EL, 100μF, ±20%, 25V
C869	24678229	EL, 2.2μF, ±20%, 200V
C870	24095802	PF, 0.068μF, 400V
C871	24092345	CD, 1000pF, ±10%, 2kV
C873	24539224	PF, 0.22μF
C874	24435221	CD, 220pF, 500V
C876	24539104	PF, 0.1μF
C884	24640018	EL, 220μF, ±20%, 160V
C885	24214471	CD, 470pF, ±10%, 500V
C889	24795471	EL, 470μF, ±20%, 25V
C891	24082229	PF, 0.1μF, ±10%, 250V
C893	24092338	CD, 270pF, ±10%, 2kV
C894	24092338	CD, 270pF, ±10%, 2kV
C898	24212101	CD, 100pF, ±10%
C902	24211102	CD, 1000pF, ±10%, 2kV

Location No.	Part No.	Description
C921	24212561	CD, 560pF, $\pm 10\%$
C922	24212681	CD, 680pF, $\pm 10\%$
C923	24212561	CD, 560pF, $\pm 10\%$
C972	24232103	CD, 0.01 μ F, +80%, -20%
CA28	24472100	CD, 10pF
CA29	24472100	CD, 10pF
CA33	24232103	CD, 0.01 μ F, +80%, -20%
CA36	24474101	CD, 100pF, $\pm 10\%$
CA37	24474101	CD, 100pF, $\pm 10\%$
CA38	24474101	CD, 100pF, $\pm 10\%$
CA42	24794100	EL, 10 μ F, $\pm 20\%$, 16V
CA43	24232103	CD, 0.01 μ F, +80%, -20%
CA68	24794100	EL, 10 μ F, $\pm 20\%$, 16V
CA69	24232103	CD, 0.01 μ F, +80%, -20%
CB01	24794470	EL, 47 μ F, $\pm 20\%$, 16V
CB20	24474101	CD, 100pF, $\pm 10\%$
CR01	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V
CR02	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V
CR03	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V
CS02	24797229	EL, 2.2 μ F, $\pm 20\%$, 50V
CS03	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V
CS10	24797479	EL, 4.7 μ F, $\pm 20\%$, 50V
CS11	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V
CT63	24591223	PF, 0.022 μ F
CV06	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V

RESISTORS

R101	24382153	OMF, 15k ohm, 1W
R102	24381560	OMF, 56 ohm, 1/2W
R103	24366681	CF, 680 ohm
R201	24552391	OMF, 390 ohm, 1/2W
R208	24366683	CF, 68k ohm
R227	24366363	CF, 36k ohm
R230	24366223	CF, 22k ohm
R233	24366152	CF, 1500 ohm
R235	24366184	CF, 180k ohm
R236	24366101	CF, 100 ohm
R237	24366101	CF, 100 ohm
R238	24366472	CF, 4700 ohm
R239	24366152	CF, 1500 ohm
R241	24366433	CF, 43k ohm
R242	24366473	CF, 47k ohm
R244	24366393	CF, 39k ohm
R245	24366274	CF, 270k ohm
R246	24366225	CF, 2.2M ohm
R301	24366102	CF, 1k ohm
R303	24366102	CF, 1k ohm
R304	24366363	CF, 36k ohm
R305	24322159	OMF, 1.5 ohm, 1W
R306	24366273	CF, 27k ohm
R307	24366334	CF, 330k ohm
R313	24366393	CF, 39k ohm
R317	24366243	CF, 24k ohm
R327	24338689	MF, 6.8 ohm, 1W
R336	24383271	OMF, 270 ohm, 2W
R337	24366223	CF, 22k ohm
R338	24366223	CF, 22k ohm
R401	24366391	CF, 390 ohm
R402	24366103	CF, 10k ohm
R403	24366332	CF, 3300 ohm
R404	24553121	OMF, 120 ohm, 1W
R405	24553392	OMF, 3900 ohm, 1W
R406	24366333	CF, 33k ohm
R407	24366223	CF, 22k ohm

Location No.	Part No.	Description
R410	24366391	CF, 390 ohm
R411	24366561	CF, 560 ohm
R416	24019325	OMF, 2200 ohm, 5W
R421	24321339	OMF, 3.3 ohm, 1/2W
R422	24366471	CF, 470 ohm
R430	24366102	CF, 1k ohm
R431	24366103	CF, 10k ohm
R432	24366222	CF, 2200 ohm
R448	24338828	MF, 0.82 ohm, 1W
R472	24376270	CF, 27 ohm, 1/2W
△R475	24367431	CF, 430 ohm, $\pm 2\%$
R476	24366823	CF, 82k ohm
R477	24366223	CF, 22k ohm
△R478	24327133	MF, 13k ohm, $\pm 1\%$, 1/4W
R481	24366333	CF, 33k ohm
△R482	24327512	MF, 5100 ohm, $\pm 1\%$, 1/4W
R503	24366334	CF, 330k ohm
R504	24366332	CF, 3300 ohm
R506	24366101	CF, 100 ohm
R507	24366101	CF, 100 ohm
R508	24366101	CF, 100 ohm
R513	24366332	CF, 3300 ohm
R514	24366332	CF, 3300 ohm
R603	24366391	CF, 390 ohm
R604	24366102	CF, 1k ohm
R605	24366339	CF, 3.3 ohm
R663	24366221	CF, 220 ohm
R808	24000209	PTC Thermistor, RZ45P2C120M1
R810	24510129	Cement, 1.2 ohm, 5W
R816	24366471	CF, 470 ohm
R818	24366561	CF, 560 ohm
R819	24366102	CF, 1k ohm
R861	24382103	OMF, 10k ohm, 1W
R862	24381220	OMF, 22 ohm, 1/2W
R864	24552102	OMF, 1k ohm, 1/2W
R866	24552470	OMF, 47 ohm, 1/2W
R870	24381271	OMF, 270 ohm, 1/2W
R871	24381820	OMF, 82 ohm, 1/2W
R872	24382104	OMF, 100k ohm, 1W
R883	24381153	OMF, 15k ohm, 1/2W
R884	24366102	CF, 1k ohm
R889	24546109	FR, 1 ohm, 1/2W
R891	24366102	CF, 1k ohm
R898	24946395	CC, 3.9M ohm, $\pm 10\%$, 1/2W
R899	24946395	CC, 3.9M ohm, $\pm 10\%$, 1/2W
R901	24376472	CF, 4700 ohm, 1/2W
R902	24376472	CF, 4700 ohm, 1/2W
R903	24376472	CF, 4700 ohm, 1/2W
R911	24366101	CF, 100 ohm
R912	24366101	CF, 100 ohm
R913	24366101	CF, 100 ohm
R920	24000568	FR, 4.7 ohm, 1W
R921	24366471	CF, 470 ohm
R922	24366471	CF, 470 ohm
R923	24366471	CF, 470 ohm
R931	24366122	CF, 1200 ohm
R932	24366122	CF, 1200 ohm
R933	24366122	CF, 1200 ohm
R941	24366680	CF, 68 ohm
R942	24366680	CF, 68 ohm
R943	24366680	CF, 68 ohm
R961	24554183	OMF, 18k ohm, 2W
R962	24554183	OMF, 18k ohm, 2W

Location No.	Part No.	Description
R963	24554183	OMF, 18k ohm, 2W
R971	24366821	CF, 820 ohm
R972	24366102	CF, 1k ohm
R973	24366391	CF, 390 ohm
R974	24366331	CF, 330 ohm
RA03	24366102	CF, 1k ohm
RA07	24366102	CF, 1k ohm
RA08	24366102	CF, 1k ohm
RA13	24366102	CF, 1k ohm
RA16	24366102	CF, 1k ohm
RA17	24366102	CF, 1k ohm
RA18	24366102	CF, 1k ohm
RA22	24366472	CF, 4700 ohm
RA23	24366472	CF, 4700 ohm
RA24	24366472	CF, 4700 ohm
RA25	24366822	CF, 8200 ohm
RA26	24366102	CF, 1k ohm
RA27	24366102	CF, 1k ohm
RA33	24366103	CF, 10k ohm
RA34	24366102	CF, 1k ohm
RA35	24366102	CF, 1k ohm
RA36	24366103	CF, 10k ohm
RA37	24366331	CF, 330 ohm
RA38	24366331	CF, 330 ohm
RA61	24366103	CF, 10k ohm
RA62	24366103	CF, 10k ohm
RA67	24366103	CF, 10k ohm
RA68	24366103	CF, 10k ohm
RA70	24366333	CF, 33k ohm
RA71	24366683	CF, 68k ohm
RA72	24366223	CF, 22k ohm
RA73	24366103	CF, 10k ohm
RB01	24366271	CF, 270 ohm
RB03	24366101	CF, 100 ohm
RB09	24366470	CF, 47 ohm
RB11	24366103	CF, 10k ohm
RB26	24366103	CF, 10k ohm
RB27	24366103	CF, 10k ohm
RB28	24366104	CF, 100k ohm
RB30	24366103	CF, 10k ohm
RB40	24366103	CF, 10k ohm
RB41	24366182	CF, 1800 ohm
RB42	24366102	CF, 1k ohm
RB43	24366103	CF, 10k ohm
RB44	24366682	CF, 6800 ohm
RB45	24366221	CF, 220 ohm
RR90	24366122	CF, 1200 ohm
RR91	24366122	CF, 1200 ohm
RR92	24366122	CF, 1200 ohm
RR93	24366472	CF, 4700 ohm
RS01	24366102	CF, 1k ohm
RT61	24366332	CF, 3300 ohm
RT63	24366102	CF, 1k ohm
RV01	24366750	CF, 75 ohm
RV03	24366390	CF, 39 ohm
COILS & TRANSFORMERS		
L301	23103859	Coil (Ferrite Bead), TEM2011
L410	23103859	Coil (Ferrite Bead), TEM2011
△L462	23231066	Deflection Yoke, TDY-314LS
L805	23248150	Coil, Choke, TLN3427
L806	23221747	Coil, Choke, TRF9253D
L862	23103859	Coil (Ferrite Bead), TEM2011
L883	23103859	Coil (Ferrite Bead), TEM2011

Location No.	Part No.	Description
L884	23103859	Coil (Ferrite Bead), TEM2011
L885	23221722	Coil, Choke, TLN3142D
L886	23103859	Coil (Ferrite Bead), TEM2011
△L901	23200283	Coil, Degaussing, TSB-2219AG
LA01	23289100	Coil, Peaking, TRF4100AF
LB01	23289560	Coil, Peaking, TRF4560
T401	23224983	Transformer, Horiz. Drive, TLN1039
△T461	23236507	Transformer, Flyback, TFB4122CS
△T801	23211663	Line Filter, TRF3194
△T840	23213513	Transformer, Power, TPW1459AZ
△T862	23217309	Transformer, Converter, TPW3318BG
SEMICONDUCTORS		
Q101	23114528	Transistor, 2SC1740S-Q
Q301	B0377890	IC, TA8403K
Q402	A6330069	Transistor, 2SC2482 FA-1
△Q404	A6871242	Transistor, 2SD1554
Q421	23314141	Transistor, 2SC3852
Q471	23114530	Transistor, 2SA933S-Q
Q472	23114528	Transistor, 2SC1740S-Q
Q501	B0385424	IC, TA1223AN
Q610	23119668	IC, TDA2611A
Q801	23905433	IC, STR-Z2753
Q817	23114528	Transistor, 2SC1740S-Q
Q818	A6012010	Transistor, RN2201
Q819	23114528	Transistor, 2SC1740S-Q
Q840	23318299	IC, L78MR05
Q843	A6002050	Transistor, RN1205
△Q862	A8643135	Photo Coupler, TLP621(GRL)
Q883	A6907777	IC, S1854 FA-4
Q901	A6330059	Transistor, 2SC2482(C)
Q902	A6330059	Transistor, 2SC2482(C)
Q903	A6330059	Transistor, 2SC2482(C)
Q971	A6534053	Transistor, 2SA1015-Y(TE
QA01	23905436	IC, TMP87CH34BN
QA02	23904938	IC, 24LC01BI/P
QB01	23114528	Transistor, 2SC1740S-Q
QB03	A6002050	Transistor, RN1205
QB21	23114528	Transistor, 2SC1740S-Q
QB30	23114528	Transistor, 2SC1740S-Q
QB40	23114528	Transistor, 2SC1740S-Q
D102	23316673	Diode, Zener, MTZJ5,6C
D201	23316292	Diode, Zener, UZ3.3BSA
D204	23115537	Diode, 1SS131
D205	23115537	Diode, 1SS131
D210	23115537	Diode, 1SS131
D301	A7568460	Diode, TVR-1B
D302	23118094	Diode, EU2A
D406	23118094	Diode, EU2A
D408	23118479	Diode, BYD33J
D410	23316325	Diode, Zener, UZ9.1BSB
D421	23316690	Diode, Zener, MTZJ10B
D441	23316324	Diode, Zener, UZ9.1BSB
D445	23118479	Diode, BYD33J
D471	A7568460	Diode, TVR-1B
△D472	23115774	Diode, Zener, RD6.2E(4)
D501	23316323	Diode, Zener, UZ9.1BSA
D502	23316323	Diode, Zener, UZ9.1BSA
D503	23316323	Diode, Zener, UZ9.1BSA
D801	A7568754	Diode, 1S1887AFA-1

Location No.	Part No.	Description
D802	A7568754	Diode, 1S1887AFA-1
D803	A7568754	Diode, 1S1887AFA-1
D804	A7568754	Diode, 1S1887AFA-1
D840	23316962	Diode, S1WBA20 4101
D845	23115537	Diode, 1SS131
D862	23118094	Diode, EU2A
D864	23118094	Diode, EU2A
D866	23316360	Diode, Zener, UZ27BSC
D875	23316333	Diode, Zener, UZ12BSB
D876	23316360	Diode, Zener, UZ27BSC
D881	23115537	Diode, 1SS131
D883	23316813	Diode, EG1
D884	23316813	Diode, EG1
D885	23118094	Diode, EU2A
△D899	24000268	Varistor, ENC271D-14A
D902	23115537	Diode, 1SS131
D903	23115537	Diode, 1SS131
DB01	23358501	Diode (LED), SCL003URC5F
DB03	23358522	LED, SIR-56SB3F
DB30	23115537	Diode, 1SS131
MISCELLANEOUS		
E502	23848729	Rubber Wedge
△F301	23144727	Fuse, 0.4A
F301A	23165433	Holder, Fuse
△F470	23144495	Fuse, 0.8A
F470A	23165433	Holder, Fuse
△F801	23144735	Fuse, 5.0A
F801A	23165433	Holder, Fuse
△F860	23144509	Fuse, 2.5A
G060	24366101	CF, 100 ohm
G101	23316694	Diode, Zener, UZT33
G204	23238714	Coil, Peaking, TRF4100AJ
G411	23103880	Coil (Ferrite Bead), TEM2011Y
G813	24092270	CD, 4700pF, ±20%, AC125V
G814	24094820	CD, 2200pF, ±20%, AC250V
G816	24094820	CD, 2200pF, ±20%, AC250V
G861	23103880	Coil (Ferrite Bead), TEM2011Y
△G882	23316653	Diode, Zener, MTZJ2.7B
KB01	23905177	Remote Sensor, PIC-TB16
P661	23365728	Jack, Earphone
△P801	23176005	Power Cord
SA01	23145227	Switch, Push, 1C1P
SA02	23145227	Switch, Push, 1C1P
SA03	23145227	Switch, Push, 1C1P
SA04	23145227	Switch, Push, 1C1P
SA05	23145227	Switch, Push, 1C1P
SA07	23145227	Switch, Push, 1C1P
△SR81	23146916	Power Relay, DG1U-12
△V901A	23902970	Socket, CRT, 8P
V901M	23102909	Magnet, Purity-Convergence, MAG-1052
W661	23351111	Speaker, SPK-1378, 77x77mm, 16 ohm
X401	23153721	Ceramic Resonator, 503kHz, TCR1023
X501	23153961	Crystal, 3.58MHz
XA01	23153325	Ceramic Resonator, 8.00M, TCR1056
PC BOARD ASSEMBLIES		
* M051Z		Main Board, PB6283-1
* M052Z		CRT Drive Board, PB6283-2

Location No.	Part No.	Description
PICTURE TUBE		
△V901	23312417	Picture Tube, A34KQV42X
TUNER		
△H001	23321188	Tuner, EL921L1
ACCESSORIES		
K912	23306161	Remote Hand Unit, CT-9852
AT03	23305976	Battery Cover
Y101	23562730	Owner's Manual, English/French, CF13F22
Y101	23562791	Owner's Manual, English/Spanish, CL14F22
Y107	23142003	Adapter, Antenna, AD-503J
Y126	23323051	Antenna, VHF Telescopic

CHASSIS REPLACEMENT PARTS LIST

WARNING: BEFORE SERVICING THIS CHASSIS, READ THE "X-RAY RADIATION PRECAUTION", "SAFETY PRECAUTION" AND "PRODUCT SAFETY NOTICE" ON PAGE 2 OF THIS MANUAL.

CAUTION: The international hazard symbols "⚠" in the schematic diagram and the parts list designate components which have special characteristics important for safety and should be replaced only with types identical to those in the original circuit or specified in the parts list. The mounting position of replacements is to be identical with originals. Before replacing any of these components, read carefully the PRODUCT SAFETY NOTICE on page 2. Do not degrade the safety of the receiver through improper servicing.

NOTICE:

- The part number must be used when ordering parts, in order to assist in processing, be sure to include the Model number and Description.
- The PC board assembly with * mark is no longer available after the end of the production.

Models : CF19F22/ CL20F22

ABBREVIATIONS:

Capacitors..... CD	: Ceramic Disk	PF	: Plastic Film	EL	: Electrolytic	
Resistors..... CF	: Carbon Film	CC	: Carbon Composition	MF	: Metal Film	
	OMF	: Oxide Metal Film	VR	: Variable Resistor	FR	: Fusible Resistor

(All CD and PF capacitors are ±5%, 50V and all resistors, ±5%, 1/6W unless otherwise noted.)

Location No.	Part No.	Description
CAPACITORS		
C101	24797100	EL, 10μF, ±20%, 50V
C102	24763101	EL, 100μF, ±20%, 16V
C103	24232103	CD, 0.01μF, +80%, -20%
C113	24794470	EL, 47μF, ±20%, 16V
C201	24797478	EL, 0.47μF, ±20%, 50V
C202	24794220	EL, 22μF, ±20%, 16V
C205	24794220	EL, 22μF, ±20%, 16V
C207	24794100	EL, 10μF, ±20%, 16V
C208	24797010	EL, 1μF, ±20%, 50V
C209	24797229	EL, 2.2μF, ±20%, 50V
C210	24794470	EL, 47μF, ±20%, 16V
C211	24232103	CD, 0.01μF, +80%, -20%
C230	24794331	EL, 330μF, ±20%, 16V
C231	24232103	CD, 0.01μF, +80%, -20%
C232	24092398	CD, 0.1μF, +80%, -20%
C233	24797100	EL, 10μF, ±20%, 50V
C235	24353080	CD, 8pF, ±0.25pF
C301	24617912	EL, 2.2μF, ±10%, 50V
C302	24212152	CD, 1500pF, ±10%
C305	24617912	EL, 2.2μF, ±10%, 50V
C306	24073043	EL, 2200μF, ±20%, 16V
C307	24082047	PF, 0.033μF, 100V
C308	24668101	EL, 100μF, ±20%, 35V
C309	24591102	PF, 1000pF
C310	24796102	EL, 1000μF, ±20%, 35V
C311	24214221	CD, 220pF, ±10%, 500V
C313	24082260	PF, 4700pF, 100V
C314	24591563	PF, 0.056μF
C315	24797229	EL, 2.2μF, ±20%, 50V
C317	24214471	CD, 470pF, ±10%, 500V
C403	24591203	PF, 0.02μF
C404	24797229	EL, 2.2μF, ±20%, 50V
C417	24214391	CD, 390pF, ±10%, 500V
C421	24794470	EL, 47μF, ±20%, 16V
C431	24794101	EL, 100μF, ±20%, 16V
△C440	24082553	PF, 9100pF, ±3%, 1250V
△C442	24082697	PF, 0.43μF, 250V
C445	24828223	PF, 0.022μF, 200V
C446	24700100	EL, 10μF, ±20%, 250V
C448	24640908	EL, 33μF, ±20%, 160V

Location No.	Part No.	Description
C449	24794102	EL, 1000μF, ±20%, 16V
C463	24212152	CD, 1500pF, ±10%
C471	24797479	EL, 4.7μF, ±20%, 50V
C474	24794100	EL, 10μF, ±20%, 16V
C504	24353090	CD, 9pF, ±0.25pF
C510	24797229	EL, 2.2μF, ±20%, 50V
C514	24591223	PF, 0.022μF
C515	24538104	PF, 0.1μF
C607	24797100	EL, 10μF, ±20%, 50V
C609	24591103	PF, 0.01μF
C610	24795220	EL, 22μF, ±20%, 25V
C611	24539104	PF, 0.1μF
C613	24794221	EL, 220μF, ±20%, 16V
C614	24797478	EL, 0.47μF, ±20%, 50V
C801	24082001	PF, 0.47μF, ±20%, AC125V
C810	24086052	EL, 220μF, ±20%, 200V
C811	24092270	CD, 4700pF, ±20%, AC400V
C812	24094820	CD, 2200pF, ±20%, AC400V
C815	24094820	CD, 2200pF, ±20%, AC400V
C819	24766478	EL, 0.47μF, ±20%, 50V
C840	24795471	EL, 470μF, ±20%, 25V
C842	24792101	EL, 100μF, ±20%, 6.3V
C843	24539104	PF, 0.1μF
C860	24214103	CD, 0.01μF, ±10%, 500V
C862	24591821	PF, 820pF
C863	24539104	PF, 0.1μF
C865	24092345	CD, 1000pF, ±10%, 2kV
C866	24669478	EL, 0.47μF, ±20%, 50V
C867	24212682	CD, 6800pF, ±10%
C868	24667101	EL, 100μF, ±20%, 25V
C869	24678229	EL, 2.2μF, ±20%, 200V
C870	24095802	PF, 0.068μF, 400V
C871	24092345	CD, 1000pF, ±10%, 2kV
C873	24539224	PF, 0.22μF
C874	24435221	CD, 220pF, 500V
C876	24539104	PF, 0.1μF
C884	24640018	EL, 220μF, ±20%, 160V
C885	24214471	CD, 470pF, ±10%, 500V
C889	24795471	EL, 470μF, ±20%, 25V
C891	24082229	PF, 0.1μF, ±10%, 250V
C893	24092338	CD, 270pF, ±10%, 2kV

Location No.	Part No.	Description
C894	24092338	CD, 270pF, $\pm 10\%$, 2kV
C898	24212101	CD, 100pF, $\pm 10\%$
C902	24211102	CD, 1000pF, $\pm 10\%$, 2kV
C921	24212821	CD, 820pF, $\pm 10\%$
C922	24212102	CD, 1000pF, $\pm 10\%$
C923	24212821	CD, 820pF, $\pm 10\%$
C972	24794220	EL, 22 μ F, $\pm 20\%$, 16V
CA28	24472100	CD, 10pF
CA29	24472100	CD, 10pF
CA33	24232103	CD, 0.01 μ F, +80%, -20%
CA36	24474101	CD, 100pF, $\pm 10\%$
CA37	24474101	CD, 100pF, $\pm 10\%$
CA38	24474101	CD, 100pF, $\pm 10\%$
CA42	24794100	EL, 10 μ F, $\pm 20\%$, 16V
CA43	24232103	CD, 0.01 μ F, +80%, -20%
CA68	24794100	EL, 10 μ F, $\pm 20\%$, 16V
CA69	24232103	CD, 0.01 μ F, +80%, -20%
CB01	24794470	EL, 47 μ F, $\pm 20\%$, 16V
CB20	24474101	CD, 100pF, $\pm 10\%$
CR01	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V
CR02	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V
CR03	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V
CS02	24797229	EL, 2.2 μ F, $\pm 20\%$, 50V
CS03	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V
CS10	24797479	EL, 4.7 μ F, $\pm 20\%$, 50V
CS11	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V
CT63	24591223	PF, 0.022 μ F
CV06	24797478	EL, 0.47 μ F, $\pm 20\%$, 50V
RESISTORS		
R101	24382153	OMF, 15k ohm, 1W
R102	24381560	OMF, 56 ohm, 1/2W
R103	24366681	CF, 680 ohm
R201	24552391	OMF, 390 ohm, 1/2W
R208	24366683	CF, 68k ohm
R227	24366273	CF, 27k ohm
R230	24366223	CF, 22k ohm
R233	24366152	CF, 1500 ohm
R235	24366184	CF, 180k ohm
R236	24366101	CF, 100 ohm
R237	24366101	CF, 100 ohm
R238	24366562	CF, 5600 ohm
R239	24366152	CF, 1500 ohm
R241	24366433	CF, 43k ohm
R242	24366473	CF, 47k ohm
R244	24366393	CF, 39k ohm
R245	24366184	CF, 180k ohm
R246	24366225	CF, 2.2M ohm
R247	24366561	CF, 560 ohm
R301	24366102	CF, 1k ohm
R303	24366102	CF, 1k ohm
R304	24366393	CF, 39k ohm
R305	24322109	MF, 1 ohm, 1W
R306	24366393	CF, 39k ohm
R307	24366624	CF, 620k ohm
R313	24366913	CF, 91k ohm
R317	24366363	CF, 36k ohm
R327	24338829	MF, 8.2 ohm, 1W
R336	24383271	OMF, 270 ohm, 2W
R337	24366223	CF, 22k ohm
R338	24366223	CF, 22k ohm
R401	24366391	CF, 390 ohm
R402	24366103	CF, 10k ohm
R403	24366332	CF, 3300 ohm

Location No.	Part No.	Description
R404	24553121	OMF, 120 ohm, 1W
R405	24553392	OMF, 3900 ohm, 1W
R406	24366333	CF, 33k ohm
R407	24366223	CF, 22k ohm
R410	24366391	CF, 390 ohm
R411	24366561	CF, 560 ohm
R412	24366560	CF, 56 ohm
R416	24510152	Cement, 1500 ohm, 5W
R421	24321339	OMF, 3.3 ohm, 1/2W
R422	24366471	CF, 470 ohm
R430	24366102	CF, 1k ohm
R431	24366103	CF, 10k ohm
R432	24366222	CF, 2200 ohm
R448	24338828	MF, 0.82 ohm, 1W
R472	24376270	CF, 27 ohm, 1/2W
△R475	24366100	CF, 10 ohm
R476	24366823	CF, 82k ohm
R477	24366223	CF, 22k ohm
△R478	24327133	MF, 13k ohm, $\pm 1\%$, 1/4W
R481	24366333	CF, 33k ohm
△R482	24327562	MF, 5600 ohm, $\pm 1\%$, 1/4W
R503	24366334	CF, 330k ohm
R504	24366332	CF, 3300 ohm
R506	24366101	CF, 100 ohm
R507	24366101	CF, 100 ohm
R508	24366101	CF, 100 ohm
R513	24366332	CF, 3300 ohm
R514	24366332	CF, 3300 ohm
R603	24366391	CF, 390 ohm
R604	24366102	CF, 1k ohm
R605	24366339	CF, 3.3 ohm
R663	24366221	CF, 220 ohm
R808	24000269	PTC Thermisotr, 7 ohm, $\pm 20\%$, AC140V
R810	24510129	Cement, 1.2 ohm, 5W
R816	24366471	CF, 470 ohm
R818	24366561	CF, 560 ohm
R819	24366102	CF, 1k ohm
R861	24382103	OMF, 10k ohm, 1W
R862	24381220	OMF, 22 ohm, 1/2W
R864	24552102	OMF, 1k ohm, 1/2W
R866	24552470	OMF, 47 ohm, 1/2W
R870	24381271	OMF, 270 ohm, 1/2W
R871	24381820	OMF, 82 ohm, 1/2W
R872	24382104	OMF, 100k ohm, 1W
R883	24381153	OMF, 15k ohm, 1/2W
R884	24366102	CF, 1k ohm
R889	24546109	FR, 1 ohm, 1/2W
R891	24366102	CF, 1k ohm
R898	24946395	CC, 3.9M ohm, $\pm 10\%$, 1/2W
R899	24946395	CC, 3.9M ohm, $\pm 10\%$, 1/2W
R901	24376472	CF, 4700 ohm, 1/2W
R902	24376472	CF, 4700 ohm, 1/2W
R903	24376472	CF, 4700 ohm, 1/2W
R911	24366101	CF, 100 ohm
R912	24366101	CF, 100 ohm
R913	24366101	CF, 100 ohm
R920	24000568	FR, 4.7 ohm, 1W
R921	24366331	CF, 330 ohm
R922	24366331	CF, 330 ohm
R923	24366331	CF, 330 ohm
R931	24366122	CF, 1200 ohm
R932	24366122	CF, 1200 ohm
R933	24366122	CF, 1200 ohm

Location No.	Part No.	Description
R941	24366220	CF, 22 ohm
R942	24366220	CF, 22 ohm
R943	24366220	CF, 22 ohm
R961	24554183	OMF, 18k ohm, 2W
R962	24554183	OMF, 18k ohm, 2W
R963	24554183	OMF, 18k ohm, 2W
R971	24366821	CF, 820 ohm
R972	24366102	CF, 1k ohm
R973	24366391	CF, 390 ohm
R974	24366331	CF, 330 ohm
RA03	24366102	CF, 1k ohm
RA07	24366102	CF, 1k ohm
RA08	24366102	CF, 1k ohm
RA13	24366102	CF, 1k ohm
RA16	24366102	CF, 1k ohm
RA17	24366102	CF, 1k ohm
RA18	24366102	CF, 1k ohm
RA22	24366472	CF, 4700 ohm
RA23	24366472	CF, 4700 ohm
RA24	24366472	CF, 4700 ohm
RA25	24366822	CF, 8200 ohm
RA26	24366102	CF, 1k ohm
RA27	24366102	CF, 1k ohm
RA33	24366103	CF, 10k ohm
RA34	24366102	CF, 1k ohm
RA35	24366102	CF, 1k ohm
RA36	24366103	CF, 10k ohm
RA37	24366331	CF, 330 ohm
RA38	24366331	CF, 330 ohm
RA61	24366103	CF, 10k ohm
RA62	24366103	CF, 10k ohm
RA67	24366103	CF, 10k ohm
RA68	24366103	CF, 10k ohm
RA70	24366333	CF, 33k ohm
RA71	24366683	CF, 68k ohm
RA72	24366223	CF, 22k ohm
RA73	24366103	CF, 10k ohm
RB01	24366271	CF, 270 ohm
RB03	24366101	CF, 100 ohm
RB09	24366470	CF, 47 ohm
RB11	24366103	CF, 10k ohm
RB26	24366103	CF, 10k ohm
RB27	24366103	CF, 10k ohm
RB28	24366104	CF, 100k ohm
RB30	24366103	CF, 10k ohm
RB40	24366103	CF, 10k ohm
RB41	24366182	CF, 1800 ohm
RB42	24366102	CF, 1k ohm
RB43	24366103	CF, 10k ohm
RB44	24366682	CF, 6800 ohm
RB45	24366221	CF, 220 ohm
RR90	24366122	CF, 1200 ohm
RR91	24366122	CF, 1200 ohm
RR92	24366122	CF, 1200 ohm
RR93	24366472	CF, 4700 ohm
RS01	24366102	CF, 1k ohm
RT61	24366332	CF, 3300 ohm
RT63	24366102	CF, 1k ohm
RV01	24366750	CF, 75 ohm
RV03	24366390	CF, 39 ohm

COILS & TRANSFORMERS

L203	23238510	Coil, Peaking, TRF4181AJ
L301	23103880	Coil (Ferrite Bead), TEM2011Y




Location No.	Part No.	Description
L410	23103880	Coil (Ferrite Bead), TEM2011Y
△L462	23231119	Deflection Yoke, TDY-320QS
L805	23248150	Coil, Choke, TLN3427
L806	23221747	Coil, Choke, TRF9253D
L862	23103880	Coil (Ferrite Bead), TEM2011Y
L883	23103880	Coil (Ferrite Bead), TEM2011Y
L884	23103880	Coil (Ferrite Bead), TEM2011Y
L885	23221722	Coil, Choke, TLN3142D
L886	23103880	Coil (Ferrite Bead), TEM2011Y
△L901	23200919	Coil, Degaussing, TSB2100
LA01	23289100	Coil, Peaking, TRF4100AF
LB01	23289560	Coil, Peaking, TRF4560
T401	23224983	Transformer, Horiz. Drive, TLN1039
△T461	23236482	Transformer, Flyback, TFB4125DD
△T801	23211668	Line Filter, TRF3199
△T840	23213513	Transformer, Power, TPW1459AZ
△T862	23217304	Transformer, Converter, TPW3318AD

SEMICONDUCTORS



Q101	23114528	Transistor, 2SC1740S-Q
Q301	B0377890	IC, TA8403K
Q402	A6330069	Transistor, 2SC2482 FA-1
△Q404	23314375	Transistor, ON4409(508D)
Q421	23314141	Transistor, 2SC3852
Q471	23114530	Transistor, 2SA933S-Q
Q472	23114528	Transistor, 2SC1740S-Q
Q501	B0385424	IC, TA1223AN
Q610	23119668	IC, TDA2611A
Q801	23905433	IC, STR-Z2753
Q817	23114528	Transistor, 2SC1740S-Q
Q818	A6012010	Transistor, RN2201
Q819	23114528	Transistor, 2SC1740S-Q
Q840	23318299	IC, L78MR05
Q843	A6002050	Transistor, RN1205
△Q862	A8643135	Photo Coupler, TLP621(GRL)
Q883	A6907777	IC, S1854 FA-4
Q901	A6330059	Transistor, 2SC2482(C)
Q902	A6330059	Transistor, 2SC2482(C)
Q903	A6330059	Transistor, 2SC2482(C)
Q971	A6534053	Transistor, 2SA1015-Y(TE
QA01	23905436	IC, TMP87CH34BN
QA02	23904938	IC, 24LC01B1/P
QB01	23114528	Transistor, 2SC1740S-Q
QB03	A6002050	Transistor, RN1205
QB21	23114528	Transistor, 2SC1740S-Q
QB30	23114528	Transistor, 2SC1740S-Q
QB40	23114528	Transistor, 2SC1740S-Q
D102	23316673	Diode, Zener, MTZJ5,6C
D201	23316292	Diode, Zener, UZ3.3BSA
D204	23115537	Diode, 1SS131
D205	23115537	Diode, 1SS131
D210	23115537	Diode, 1SS131
D301	A7568460	Diode, TVR-1B
D302	23118094	Diode, EU2A
D406	23118094	Diode, EU2A
D408	23118479	Diode, BYD33J
D410	23316325	Diode, Zener, UZ9.1BSC
D421	23316690	Diode, Zener, MTZJ10B
D441	23316324	Diode, Zener, UZ9.1BSB
D445	23118479	Diode, BYD33J


Location No.	Part No.	Description
D471	A7568460	Diode, TVR-1B
△D472	23115774	Diode, Zener, RD6.2E(4)
D501	23316323	Diode, Zener, UZ9.1BSA
D502	23316323	Diode, Zener, UZ9.1BSA
D503	23316323	Diode, Zener, UZ9.1BSA
D801	A7568754	Diode, 1S1887AFA-1
D802	A7568754	Diode, 1S1887AFA-1
D803	A7568754	Diode, 1S1887AFA-1
D804	A7568754	Diode, 1S1887AFA-1
D840	23316962	Diode, S1WBA20 4101
D845	23115537	Diode, 1SS131
D862	23118094	Diode, EU2A
D864	23118094	Diode, EU2A
D866	23316360	Diode, Zener, UZ27BSC
D875	23316333	Diode, Zener, UZ12BSB
D876	23316360	Diode, Zener, UZ27BSC
D881	23115537	Diode, 1SS131
D883	23316813	Diode, EG1
D884	23316813	Diode, EG1
D885	23118094	Diode, EU2A
△D899	24000268	Varistor, ENC271D-14A
D902	23115537	Diode, 1SS131
D903	23115537	Diode, 1SS131
DB01	23358501	Diode (LED), SCL003URC5F
DB03	23358522	LED, SIR-56SB3F
DB30	23115537	Diode, 1SS131
MISCELLANEOUS		
E502	23848729	Rubber Wedge
△F301	23144727	Fuse, 0.4A
F301A	23165433	Holder, Fuse
△F470	23144495	Fuse, 0.8A
F470A	23165433	Holder, Fuse
△F801	23144888	Fuse, 5.0A, 125V
F801A	23165433	Holder, Fuse
△F860	23144509	Fuse, 2.5A
G060	24366101	CF, 100 ohm
G101	23316694	Diode, Zener, UZT33
G204	23238714	Coil, Peaking, TRF4100AJ
G411	23103880	Coil (Ferrite Bead), TEM2011Y
G813	24092270	CD, 4700pF, ±20%, AC125V
G814	24094820	CD, 2200pF, ±20%, AC250V
G816	24094820	CD, 2200pF, ±20%, AC250V
G861	23103880	Coil (Ferrite Bead), TEM2011Y
△G882	23316653	Diode, Zener, MTZJ2.7B
KB01	23905177	Remote Sensor, PIC-TB16
P661	23365728	Jack, Eerphone
△P801	23176004	Power Cord
SA01	23145227	Switch, Push, 1C1P
SA02	23145227	Switch, Push, 1C1P
SA03	23145227	Switch, Push, 1C1P
SA04	23145227	Switch, Push, 1C1P
SA05	23145227	Switch, Push, 1C1P
SA07	23145227	Switch, Push, 1C1P
△SR81	23146916	Power Relay, DG1U-12
△V901A	23902021	Socket, CRT, 8P
V901M	23102409	Magnet, P/C, MAG-1070
W661	23351111	Speaker, SPK-1378, 77x77mm, 16 ohm
X401	23153721	Ceramic Resonator, 503kHz, TCR1023
X501	23153961	Crystal, 3.58MHz
XA01	23153325	Ceramic Resonator, 8.00M, TCR1056

Location No.	Part No.	Description
PC BOARD ASSEMBLIES		
* M051Z		Main Board, PB6221-1
* M052Z		CRT Drive Board, PB6221-2
PICTURE TUBE		
△V901	23312676	Picture Tube, A48KZL70X(LW)
TUNER		
△H001	23321224	Tuner, EL921L2
ACCESSORIES		
K912	23306161	Remote Hand Unit, CT-9852
AT03	23305976	Battery Cover
Y101	23562704	Owner's Manual, English, CF19F22
Y101	23562763	Owner's Manual, English/Spanish, CL20F22
Y101F	23562705	Owner's Manual, French, CF19F22
Y107	23142003	Adapter, Antenna, AD-503J (CL20F22)
Y126	23124866	Antenna, VHF Telescopic (CL20F22)



PAIR USE	
R1	S1854FA-4
R2	S1854FA
R3	S1854A-1
Q883	Q882
R1	S1854FA-4
R2	S1854FA
R3	S1854A-1
Q819	Q818
R1	S1854FA-4
R2	S1854FA
R3	S1854A-1





D899
TNR15G271K
or ENC271D-14A

P801 090
P802 2P
P803 3P
P804 4P
P805 5P
P806 6P
P807 7P
P808 8P
P809 9P
P810 10P
P811 11P
P812 12P
P813 13P
P814 14P
P815 15P
P816 16P
P817 17P
P818 18P
P819 19P
P820 20P

P821 21P
P822 22P
P823 23P
P824 24P
P825 25P
P826 26P
P827 27P
P828 28P
P829 29P
P830 30P

P831 31P
P832 32P
P833 33P
P834 34P
P835 35P
P836 36P
P837 37P
P838 38P
P839 39P
P840 40P

P841 41P
P842 42P
P843 43P
P844 44P
P845 45P
P846 46P
P847 47P
P848 48P
P849 49P
P850 50P

P851 51P
P852 52P
P853 53P
P854 54P
P855 55P
P856 56P
P857 57P
P858 58P
P859 59P
P860 60P

P861 61P
P862 62P
P863 63P
P864 64P
P865 65P
P866 66P
P867 67P
P868 68P
P869 69P
P870 70P

P871 71P
P872 72P
P873 73P
P874 74P
P875 75P
P876 76P
P877 77P
P878 78P
P879 79P
P880 80P

P881 81P
P882 82P
P883 83P
P884 84P
P885 85P
P886 86P
P887 87P
P888 88P
P889 89P
P890 90P

P891 91P
P892 92P
P893 93P
P894 94P
P895 95P
P896 96P
P897 97P
P898 98P
P899 99P
P900 100P

P901 101P
P902 102P
P903 103P
P904 104P
P905 105P
P906 106P
P907 107P
P908 108P
P909 109P
P910 110P

P911 111P
P912 112P
P913 113P
P914 114P
P915 115P
P916 116P
P917 117P
P918 118P
P919 119P
P920 120P

P921 121P
P922 122P
P923 123P
P924 124P
P925 125P
P926 126P
P927 127P
P928 128P
P929 129P
P930 130P

P931 131P
P932 132P
P933 133P
P934 134P
P935 135P
P936 136P
P937 137P
P938 138P
P939 139P
P940 140P

P941 141P
P942 142P
P943 143P
P944 144P
P945 145P
P946 146P
P947 147P
P948 148P
P949 149P
P950 150P

P951 151P
P952 152P
P953 153P
P954 154P
P955 155P
P956 156P
P957 157P
P958 158P
P959 159P
P960 160P

P961 161P
P962 162P
P963 163P
P964 164P
P965 165P
P966 166P
P967 167P
P968 168P
P969 169P
P970 170P

P971 171P
P972 172P
P973 173P
P974 174P
P975 175P
P976 176P
P977 177P
P978 178P
P979 179P
P980 180P

P981 181P
P982 182P
P983 183P
P984 184P
P985 185P
P986 186P
P987 187P
P988 188P
P989 189P
P990 190P

P991 191P
P992 192P
P993 193P
P994 194P
P995 195P
P996 196P
P997 197P
P998 198P
P999 199P
P1000 200P

P1001 201P
P1002 202P
P1003 203P
P1004 204P
P1005 205P
P1006 206P
P1007 207P
P1008 208P
P1009 209P
P1010 210P

P1011 211P
P1012 212P
P1013 213P
P1014 214P
P1015 215P
P1016 216P
P1017 217P
P1018 218P
P1019 219P
P1020 220P

P1021 221P
P1022 222P
P1023 223P
P1024 224P
P1025 225P
P1026 226P
P1027 227P
P1028 228P
P1029 229P
P1030 230P

P1031 231P
P1032 232P
P1033 233P
P1034 234P
P1035 235P
P1036 236P
P1037 237P
P1038 238P
P1039 239P
P1040 240P

P1041 241P
P1042 242P
P1043 243P
P1044 244P
P1045 245P
P1046 246P
P1047 247P
P1048 248P
P1049 249P
P1050 250P

P1051 251P
P1052 252P
P1053 253P
P1054 254P
P1055 255P
P1056 256P
P1057 257P
P1058 258P
P1059 259P
P1060 260P

P1061 261P
P1062 262P
P1063 263P
P1064 264P
P1065 265P
P1066 266P
P1067 267P
P1068 268P
P1069 269P
P1070 270P

P1071 271P
P1072 272P
P1073 273P
P1074 274P
P1075 275P
P1076 276P
P1077 277P
P1078 278P
P1079 279P
P1080 280P

P1081 281P
P1082 282P
P1083 283P
P1084 284P
P1085 285P
P1086 286P
P1087 287P
P1088 288P
P1089 289P
P1090 290P

P1091 291P
P1092 292P
P1093 293P
P1094 294P
P1095 295P
P1096 296P
P1097 297P
P1098 298P
P1099 299P
P1100 300P

P1101 301P
P1102 302P
P1103 303P
P1104 304P
P1105 305P
P1106 306P
P1107 307P
P1108 308P
P1109 309P
P1110 310P

P1111 311P
P1112 312P
P1113 313P
P1114 314P
P1115 315P
P1116 316P
P1117 317P
P1118 318P
P1119 319P
P1120 320P

P1121 321P
P1122 322P
P1123 323P
P1124 324P
P1125 325P
P1126 326P
P1127 327P
P1128 328P
P1129 329P
P1130 330P

P1131 331P
P1132 332P
P1133 333P
P1134 334P
P1135 335P
P1136 336P
P1137 337P
P1138 338P
P1139 339P
P1140 340P

P1141 341P
P1142 342P
P1143 343P
P1144 344P
P1145 345P
P1146 346P
P1147 347P
P1148 348P
P1149 349P
P1150 350P

P1151 351P
P1152 352P
P1153 353P
P1154 354P
P1155 355P
P1156 356P
P1157 357P
P1158 358P
P1159 359P
P1160 360P

P1161 361P
P1162 362P
P1163 363P
P1164 364P
P1165 365P
P1166 366P
P1167 367P
P1168 368P
P1169 369P
P1170 370P

P1171 371P
P1172 372P
P1173 373P
P1174 374P
P1175 375P
P1176 376P
P1177 377P
P1178 378P
P1179 379P
P1180 380P

P1181 381P
P1182 382P
P1183 383P
P1184 384P
P1185 385P
P1186 386P
P1187 387P
P1188 388P
P1189 389P
P1190 390P

P1191 391P
P1192 392P
P1193 393P
P1194 394P
P1195 395P
P1196 396P
P1197 397P
P1198 398P
P1199 399P
P1200 400P

P1201 401P
P1202 402P
P1203 403P
P1204 404P
P1205 405P
P1206 406P
P1207 407P
P1208 408P
P1209 409P
P1210 410P

P1211 411P
P1212 412P
P1213 413P
P1214 414P
P1215 415P
P1216 416P
P1217 417P
P1218 418P
P1219 419P
P1220 420P

P1221 421P
P1222 422P
P1223 423P
P1224 424P
P1225 425P
P1226 426P
P1227 427P
P1228 428P
P1229 429P
P1230 430P

P1231 431P
P1232 432P
P1233 433P
P1234 434P
P1235 435P
P1236 436P
P1237 437P
P1238 438P
P1239 439P
P1240 440P

P1241 441P
P1242 442P
P1243 443P
P1244 444P
P1245 445P
P1246 446P
P1247 447P
P1248 448P
P1249 449P
P1250 450P

P1251 451P
P1252 452P
P1253 453P
P1254 454P
P1255 455P
P1256 456P
P1257 457P
P1258 458P
P1259 459P
P1260 460P

P1261 461P
P1262 462P
P1263 463P
P1264 464P
P1265 465P
P1266 466P
P1267 467P
P1268 468P
P1269 469P
P1270 470P

P1271 471P
P1272 472P
P1273 473P
P1274 474P
P1275 475P
P1276 476P
P1277 477P
P1278 478P
P1279 479P
P1280 480P

P1281 481P
P1282 482P
P1283 483P
P1284 484P
P1285 485P
P1286 486P
P1287 487P
P1288 488P
P1289 489P
P1290 490P

P1291 491P
P1292 492P
P1293 493P
P1294 494P
P1295 495P
P1296 496P
P1297 497P
P1298 498P
P1299 499P
P1300 500P

P1301 501P
P1302 502P
P1303 503P
P1304 504P
P1305 505P
P1306 506P
P1307 507P
P1308 508P
P1309 509P
P1310 510P

P1311 511P
P1312 512P
P1313 513P
P1314 514P
P1315 515P
P1316 516P
P1317 517P
P1318 518P
P1319 519P
P1320 520P

P1321 521P
P1322 522P
P1323 523P
P1324 524P
P1325 525P
P1326 526P
P1327 527P
P1328 528P
P1329 529P
P1330 530P

P1331 531P
P1332 532P
P1333 533P
P1334 534P
P1335 535P
P1336 536P
P1337 537P
P1338 538P
P1339 539P
P1340 540P

P1341 541P
P1342 542P
P1343 543P
P1344 544P
P1345 545P
P1346 546P
P1347 547P
P1348 548P
P1349 549P
P1350 550P

P1351 551P
P1352 552P
P1353 553P
P1354 554P
P1355 555P
P1356 556P
P1357 557P
P1358 558P
P1359 559P
P1360 560P

P1361 561P
P1362 562P
P1363 563P
P1364 564P
P1365 565P
P1366 566P
P1367 567P
P1368 568P
P1369 569P
P1370 570P

P1371 571P
P1372 572P
P1373 573P
P1374 574P
P1375 575P
P1376 576P
P1377 577P
P1378 578P
P1379 579P
P1380 580P

P1381 581P
P1382 582P
P1383 583P
P1384 584P
P1385 585P
P1386 586P
P1387 587P
P1388 588P
P1389 589P
P1390 590P

P1391 591P
P1392 592P
P1393 593P
P1394 594P
P1395 595P
P1396 596P
P1397 597P
P1398 598P
P1399 599P
P1400 600P

P1401 601P
P1402 602P
P1403 603P
P1404 604P
P1405 605P
P1406 606P
P1407 607P
P1408 608P
P1409 609P
P1410 610P

P1411 611P
P1412 612P
P1413 613P
P1414 614P
P1415 615P
P1416 616P
P1417 617P
P1418 618P
P1419 619P
P1420 620P

P1421 621P
P1422 622P
P1423 623P
P1424 624P
P1425 625P
P1426 626P
P1427 627P
P1428 628P
P1429 629P
P1430 630P

P1431 631P
P1432 632P
P1433 633P
P1434 634P
P1435 635P
P1436 636P
P1437 637P
P1438 638P
P1439 639P
P1440 640P

P1441 641P
P1442 642P
P1443 643P
P1444 644P
P1445 645P
P1446 646P
P1447 647P
P1448 648P
P1449 649P
P1450 650P

P1451 651P
P1452 652P
P1453 653P
P1454 654P
P1455 655P
P1456 656P
P1457 657P
P1458 658P
P1459 659P
P1460 660P

P1461 661P
P1462 662P
P1463 663P
P1464 664P
P1465 665P
P1466 666P
P1467 667P
P1468 668P
P1469 669P
P1470 670P

P1471 671P
P1472 672P
P1473 673P
P1474 674P
P1475 675P
P1476 676P
P1477 677P
P1478 678P
P1479 679P
P1480 680P

P1481 681P
P1482 682P
P1483 683P
P1484 684P
P1485 685P
P1486 686P
P1487 687P
P1488 688P
P1489 689P
P1490 690P

P1491 691P
P1492 692P
P1493 693P
P1494 694P
P1495 695P
P1496 696P
P1497 697P
P1498 698P
P1499 699P
P1500 700P

P1501 701P
P1502 702P
P1503 703P
P1504 704P
P1505 705P
P1506 706P
P1507 707P
P1508 708P
P1509 709P
P1510 710P

P1511 711P
P1512 712P
P1513 713P
P1514 714P
P1515 715P
P1516 716P
P1517 717P
P1518 718P
P1519 719P
P1520 720P

P1521 721P
P1522 722P
P1523 723P
P1524 724P
P1525 725P
P1526 726P
P1527 727P
P1528 728P
P1529 729P
P1530 730P

P1531 731P
P1532 732P
P1533 733P
P1534 734P
P1535 735P
P1536 736P
P1537 737P
P1538 738P
P1539 739P
P1540 740P

P1541 741P
P1542 742P
P1543 743P
P1544 744P
P1545 745P
P1546 746P
P1547 747P
P1548 748P
P1549 749P
P1550 750P

P1551 751P
P1552 752P
P1553 753P
P1554 754P
P1555 755P
P1556 756P
P1557 757P
P1558 758P
P1559 759P
P1560 760P

P1561 761P
P1562 762P
P1563 763P
P1564 764P
P1565 765P
P1566 766P
P1567 767P
P1568 768P
P1569 769P
P1570 770P

P1571 771P
P1572 772P
P1573 773P
P1574 774P
P1575 775P
P1576 776P
P1577 777P
P1578 778P
P1579 779P
P1580 780P

P1581 781P
P1582 782P
P1583 783P
P1584 784P
P1585 785P
P1586 786P
P1587 787P
P1588 788P
P1589 789P
P1590 790P